


Plantation Shutters


Installation Options & How to Measure



Recess-Mount

Shutter is fitted **INSIDE** the window frame. Always check clearance for window sills, winders and other hardware.

- Measure the frame opening by taking multiple internal measurements as shown.
- Always use smallest measurement to ensure shutter fits correctly.
- Packers are included to add up to 20mm extra Width & Height. [SEE SIZE GUIDE FOR DETAILS.](#)



Face-Mount

Shutter is fitted **OUTSIDE** the window frame onto either the architrave (preferred) or wall.

- Measure the area by taking multiple external measurements as shown.
- Always use accurate measurements to ensure shutter provides full coverage.
- Packers are designed for recess-mount applications but can be used for extra width/height if desired. [SEE SIZE GUIDE FOR DETAILS.](#)

Require some more assistance?

Customer Service: 1300 155 355 or info@pillarproducts.com.au